



Inspection Services, Inc.
P.O. Box 143, Middle Grove, NY 12850

Post Chlorination Instructions:

- 1) After the well is chlorinated and the water is brought into each fixture, the water must sit in the well and pipes for a minimum of 4 hours. *Limit water use in the house to a minimum during this time.
- 2) Using a garden hose, run the water from an outside spigot into an area of the yard that is not a concern for killing grass/plants and away from any running water sources.
- 3) Run the water until no chlorine odor, taste, or color is noted – this can range from 30 minutes to 2+ hours, depending upon well conditions.
- 4) Once no further chlorine is present, the water in the house can be run as usual.
- 5) Note: if water treatment was placed in bypass during the chlorination process, it may now be put back into service.

*It is best practice to limit the amount of chlorinated water that reaches the septic system, as the system relies on bacteria to break down septic material. Some claim that using a Bioactive Septic Treatment after well chlorination may be beneficial to restore bacteria.

If you have any questions or concerns, please feel free to reach me at 518-396-9499 or e-mail me at Itiswellinspections@gmail.com.

Thank you for your business!

Sandra Baldwin MS, CWD/PI
President